



See all of the features that make Hygiena's ATP Cleaning Verification System the preferred choice of hospitals and healthcare facilities worldwide.

# SystemSURE Plus + UltraSnap<sup>®</sup> ATP CLEANING VERIFICATION SYSTEM SPECIFICATIONS



200 programmable user ID's to track staff performance.

Powered by 2 AA batteries for 8+ months of uninterrupted testing.

Online training videos and instructional guides available.

Organize test locations into plans (i.e., departments, floors, buildings, etc).

5,000 programmable test locations.

Self-checks calibration at startup.

Advanced sensor technology is durable and stays in calibration for years.

Connects to PC via USB.

Pass, Caution, or Fail result symbols are easy to interpret for any user.

100% recyclable plastic.

Easy 3-step activation requires minimal training.

Catalog No:  
**SS3H** SystemSURE Plus & SureTrend Software  
**US2020** UltraSnap Surface ATP Swabs (100)

Patented device design and unique liquid-stable chemistry provides consistent, reliable results.

Lightweight, hand-held design is convenient for one hand use.

15 month shelf life at refrigerated temperatures, 4 weeks at room temperature.

Pre-moistened swab bud breaks through biofilm for maximum sample collection.





- ✓ **TRACK TEST RESULTS**
- ✓ **QUICKLY IDENTIFY PROBLEM AREAS**
- ✓ **ANALYZE CLEANING EFFECTIVENESS**
- ✓ **AUTOMATICALLY GENERATE REPORTS**
- ✓ **FACILITATE CONTINUOUS IMPROVEMENT**

#### BENEFITS

- Free upgrades
- No licensing fees
- Unlimited technical support
- Fraud-proof data protection
- Localized data storage
- Password protection
- PC/Windows Software

## HOSPITAL HYGIENE IN YOUR INBOX

SureTrend automatically e-mails charts and reports to as many recipients as you wish.

## 40+ PRE-SET REPORTS

Customizing charts and reports is only a few clicks away. With dozens of pre-set reports, managers can start analyzing data immediately.

## GLOBAL LOCATION DIRECTORY

Infection Control and EVS can collaborate to create a master list of locations to be tested in a hospital system and share that list with any user in their network.

## NETWORK YOUR GROUP

SureTrend may be installed on a network server to link devices, departments, or even hospitals.

## MORE MEANINGFUL HUDDLES

Use the charts and graphs generated by SureTrend as visual aids to illustrate a problem, motivate team members, and work towards a common goal.

## TEST PLAN RANDOMIZATION

Randomization offers truly statistical coverage for facilities that wish to monitor 100% of locations over time without testing every location daily.